MODERN SENSE FURNITURE

Vertical Storage Solutions

modernsensefurniture.com

A quick planning guide for bookcases and shelving

Six steps before you buy

1. **Measure floor-to-ceiling height where the piece will stand**
   Check for bulkheads, sprinkler heads, or duct drops that lower the usable height in that exact spot.
2. **Find out what the wall is made of**
   Use a stud finder to confirm wood or steel stud, poured concrete, or drywall alone before you shop for anchors.
3. **Decide open shelving, closed cabinets, or a mix**
   Open shelving displays everything; closed sections at the base hide cables and clutter.
4. **Plan the proportions before you buy**
   A piece that runs at least two-thirds of the ceiling height reads as intentional; anything shorter can look undersized.
5. **Confirm the anchor kit for your wall type**
   Ask your design consultant which angle brace or strap fits the piece and the wall you are mounting to.
6. **Style the top shelves as display, not storage**
   Treat the highest shelves as a place for a single object or a plant, not an overflow zone.

Want help planning your space?

modernsensefurniture.com/contact | Book an interior design consultation

This guide is general information, not professional design advice. Sizes and specifications vary by manufacturer and change over time. Confirm details with a Modern Sense Furniture consultant or the manufacturer before you buy. Modern Sense Furniture is not liable for decisions made solely on the basis of this guide.